



Disinfection Instructions Tecnau Machines

This document describes how to disinfect Tecnau machine surfaces to minimize the risk of contracting illness through contact.

Required Items:

- latex or nitrile disposable gloves
- bottle (not a spray bottle) containing 70% isopropyl alcohol and 30% water
- lint-free cloths



WARNING!

Turn off the machine before servicing!



WARNING!

Ensure there is adequate ventilation before beginning! Avoid contact between skin and alcohol solution.



CAUTION

Apply alcohol/water mixture only onto the lint-free cloth—never directly onto any part of the machine. Keep excessive liquid off the touchscreen and display panels.

Part Number 963089
Revision A - April 6, 2020
Copyright © 2020 Tecnau

Procedure:

1. Put on the recommended disposable gloves.
2. Generously moisten a lint-free cloth with the alcohol/water solution.
3. Beginning with the touchscreen, wipe the desired surface down using the moistened cloth.

NOTE: Wipe touchscreen surfaces in one direction only; do not use circular motions.

4. Wait a few moments and then thoroughly dry the surface with another lint-free cloth.
5. Clean all exposed surfaces, operating levers or controls, and exposed cables.

NOTE: It is recommended that cables be cleaned last.

6. When you are finished disinfecting the machine:
 - a. Properly dispose of the cleaning cloths.
 - b. Carefully remove the gloves and dispose of them in the same manner.
 - c. Wash your hands for 20 seconds with soap and water.